

WIRELESS KEYBOARD HYPERONE GEN 2



Instruction

1. Battery and charging status indicator light

The light will flash yellow when the battery is low, and it will turn red when charging.

2. Connection indicator light - Receiver 2.4G

When switching to the 2.4G connection, the light will flash yellow. Simply plug the 2.4G USB into your computer to establish the connection. At this point, the light will turn off.

3. Bluetooth connection indicator light 4. Switch Power 5. Charging Port

*The instructional document is provided by HyperWork Vietnam. If you find any errors please contact us via the website <https://hyperwork.vn/>.

Bluetooth Connection Guide

To use Bluetooth connection, slide the switch to the "Bluetooth" symbol on the top of the keyboard.

Press and hold "FN" + one of the three keys 1/2/3 until the light flashes blue to enter pairing mode.

Turn on the device you want to pair, search for "HyperOne Gen 2". When the connection is successful, the indicator light will stop flashing.



1. The Keyboard can be connected to three devices, by pressing FN + 1/2/3 you can switch between connected devices.

2. To reset the keyboard, long press FN + ESC to recover factory settings of the keyboard. (this operation will clear previously connected devices)

FN+ Multimedia combination key and other function keys

There are different shortcut keys and operating mode between Windows system and MacOS system



F1 = System brightness -
F2 = System brightness +
F3 = Mission Control
F4 = Searching
F5 = Screen Shot
F6 = Sleep

F7 = Prev Song
F8 = Play | Pause
F9 = Next Song
F10 = Volume Mute
F11 = Volume -
F12 = Volume +

Connections

Bluetooth 5.1, Wireless 2.4G

Dimension

Height: 0.6 - 1.2 cm | Width: 28 cm
Depth: 12 cm | Weight: 295 g

Battery Capacity - Life

350 mAh - Up to 5 Months

Compatibility

Windows, MacOS, Android Devices

Charging Port

USB Type C

Warranty Check

Scan the QR code and enter Product Serial



Fn + F1 = System brightness -
Fn + F2 = System brightness +
Fn + F3 = Task View
Fn + F4 = Searching
Fn + F5 = Voice Recording (Windows 11)
Fn + F6 = Lock Windows

Fn + F7 = Prev Song
Fn + F8 = Play | Pause
Fn + F9 = Next Song
Fn + F10 = Volume Mute
Fn + F11 = Volume -
Fn + F12 = Volume +

If you encounter connection issues, try the following methods:

A. Reset all connections

1. Hold Fn + ESC for 5 seconds. The keyboard will reset all connections.
2. Unplug the USB and plug it back in if you use a 2.4G connection. Reconnect Bluetooth if you use a Bluetooth connection

B. Error of not being able to connect to the receiver

1. Unplug the receiver from the currently connected device
2. Press FN + 4 and hold for 5 seconds when the keyboard turns into a flashing red light, then plugging the receiver back in will fix the error.

BÀN PHÍM KHÔNG DÂY HYPERONE GEN 2



Hướng dẫn

1. Đèn báo trạng thái pin và sạc

Đèn sẽ nhấp nháy màu vàng khi pin yếu và sẽ chuyển sang màu đỏ khi sạc.

2. Đèn báo kết nối - Đầu thu 2.4G

Khi trượt nút chuyển chế độ (4) sang kết nối 2.4G đèn sẽ nhấp nháy màu vàng. Cắm USB 2.4G vào máy tính của bạn để thiết lập kết nối. Lúc này đèn sẽ tắt và có thể bắt đầu sử dụng.

3. Đèn báo kết nối Bluetooth 4. Chuyển chế độ 5. Cổng sạc

*Tài liệu hướng dẫn được cung cấp bởi HyperWork Việt Nam, nếu bạn phát hiện ra sai sót vui lòng liên hệ chúng tôi qua website <https://hyperwork.vn/>

Hướng dẫn kết nối Bluetooth

Để sử dụng kết nối Bluetooth, hãy gạt nút chuyển chế độ (4) sang biểu tượng "Bluetooth" trên bàn phím.

Nhấn và giữ "FN" + một trong ba phím 1/2/3 cho đến khi đèn nhấp nháy màu xanh lam để vào chế độ ghép nối.

Tìm kiếm "HyperOne Gen 2". Khi kết nối thành công, đèn báo sẽ ngừng nhấp nháy.



1. Bàn phím có thể được kết nối với 3 thiết bị, bằng cách nhấn FN + 1/2/3 bạn có thể chuyển đổi giữa các thiết bị được kết nối.

2. Để đặt lại bàn phím, nhấn và giữ FN + ESC để khôi phục cài đặt gốc của bàn phím (thao tác này sẽ xóa các thiết bị đã kết nối trước đó).

Phím kết hợp đa phương tiện FN+ và các phím chức năng khác

Có các phím tắt và chế độ hoạt động khác nhau giữa hệ thống MacOS và Windows



F1 = Giảm độ sáng màn hình
F2 = Tăng độ sáng màn hình
F3 = Các cửa sổ đang mở - Mission Control
F4 = Tìm kiếm
F5 = Chụp ảnh màn hình
F6 = Chế độ Sleep

F7 = Bài hát trước
F8 = Chơi | Tạm dừng
F9 = Bài hát tiếp theo
F10 = Im lặng
F11 = Giảm âm lượng
F12 = Tăng âm lượng

Chế độ kết nối

Bluetooth 5.1, Wireless 2.4G

Thông số

Dài: 28 cm | Rộng: 12 cm
Cao: 0.60 - 1.2 cm | Trọng lượng: 295 g

Thời lượng pin

350 mAh - Lên tới 5 tháng sử dụng

Tương thích

Windows, MacOS, Thiết bị Android, iOS

Cổng sạc

USB Type C

Check bảo hành

Quét mã QR và nhập Serial sản phẩm



Fn + F1 = Giảm độ sáng màn hình
Fn + F2 = Tăng độ sáng màn hình
Fn + F3 = Các cửa sổ đang mở - Task View
Fn + F4 = Tìm kiếm
Fn + F5 = Ghi âm (Windows 11)
Fn + F6 = Khóa Windows

Fn + F7 = Bài hát trước
Fn + F8 = Chơi | Tạm dừng
Fn + F9 = Bài hát tiếp theo
Fn + F10 = Im lặng
Fn + F11 = Giảm âm lượng
Fn + F12 = Tăng âm lượng

Nếu bạn gặp phải các vấn đề liên quan đến kết nối, hãy thử:

A. Reset toàn bộ kết nối

1. Giữ Fn + ESC trong 5 giây. Bàn phím sẽ cài đặt lại toàn bộ kết nối.
2. Rút USB ra và cắm lại nếu bạn sử dụng kết nối 2.4G. Kết nối lại Bluetooth nếu bạn sử dụng kết nối Bluetooth.

B. Lỗi không kết nối được receiver

1. Rút receiver khỏi thiết bị đang được kết nối.
2. Nhấn FN + 4 giữ 5 giây khi bàn phím chuyển sang đèn đỏ nhấp nháy, lúc đó cắm lại receiver vào sẽ khắc phục được lỗi.