

[ENG]

Failure to read, thoroughly understand, and follow all instructions can result in serious personal injury, damage to equipment, or voiding of factory warranty.

INSTRUCTIONS OF SAFETY AND WARNINGS:

- Make sure that the mounting surface is strong enough to handle a mounted product and heavy equipment.
- DO NOT EXCEED THE MAXIMUM LISTED WEIGHT CAPACITY.
- Always be sure to have someone assist you or a mechanical device to lift and position heavy products safely.
- Tighten screws firmly, but do not over tighten. Over tightening can cause product damage that greatly reduces the holding power.
- Keep a clear area and distance from moving parts when using the product.
- Use only as intended. Never stand, hang or climb on the product.
- This product is intended for indoor use only.
- Any attempts to reconstruct the construction aren't allowed.
- This product may contain small items that could be a choking hazard if swallowed. Keep children away unless the product is intended for their use and all instructions and manuals are fully reviewed and understood by them.
- Check that the product is secure and safe to use at regular intervals (at least every three months).




*Instructions are provided by HyperWork Vietnam, if you discover errors. Please contact us via website <https://hyperwork.vn/>

INSTRUCTION MANUAL

ERA STAND

HPW – TVC03



VESA Compatible
Max. 600x400

Screen Size
37" ~86"

Height Range
150mm (5.9")








Weight Capacity
TV 80kg/Shelf 10kg







6









8

Hang the TV on the top bracket to make sure the proper mounting holes for the Lower Hooks (L), then remove the TV and attach the lower hooks as shown.

7

													
A (x1)	B (x2)	C (x3)	D (x2)	E (x2)					M-A (x4) M6x14	M-B (x4) M8x16			
													
F (x2)	G (x1)	H (x1)	I (x4)	J (x2)	K (x4)	L (x2)					M-C (x4) M6x30	M-D (x4) M8x35	
													
M (x6) M8x45	N (x16) M6x12	O (x10) M5x8	P (x2) M5x18	Q (x1) 4mm	R (x1) 5mm(Long Type)	S (x1) 14mm						M-E (x4) D8	M-F (x4) Ø15xØ8x5
													M-G (x4) Ø15xØ8x15




To avoid mismatching during installation, do not fully tighten the screws until step 5.	
1 Note: The Components H and G aren't interchangeable.   UNLOCK LOCK Lock the brakes on the casters to avoid any sudden movements during installation.	
2  2+	
3  Leave a gap 4mm	
4 	
5  Note: Tighten the four screws M that used to fix brackets, and then tighten all of other screws.	

 A (x1)  B (x2)  C (x3)  D (x2)  E (x2)								 M-A (x4) M6x14	 M-B (x4) M8x16
 F (x2)  G (x1)  H (x1)  I (x4)  J (x2)  K (x4)  L (x2)								 M-C (x4) M6x30	 M-D (x4) M8x35
 M (x6) M8x45  N (x16) M6x12  O (x10) M5x8  P (x2) M5x18  Q (x1) 4mm  R (x1) 5mm(Long Type)  S (x1) 14mm								 M-E (x4) D8	 M-F (x4) Ø15xØ8x5
 M-G (x4) Ø15xØ8x15									


Để tránh việc không khớp trong quá trình lắp đặt, không siết chặt vít hoàn toàn cho đến bước 5.

1

Lưu ý: Các thành phần **H** và **G** không thể hoán đổi cho nhau.




Khóa phanh trên các bánh xe để tránh bất kỳ chuyển động đột ngột nào trong quá trình lắp đặt.




Nếu kệ **A** khó lắp đặt, bạn có thể điều chỉnh các vít đã cài sẵn trên kệ để làm cho việc lắp đặt trở nên dễ dàng.


2




3



4



5



Lưu ý: Siết chặt bốn vít **M** dùng để cố định các giá đỡ, sau đó siết chặt tất cả các vít còn lại.

